

MAINTENANCE MANUAL

YAMADA AIR-OPERATED DOUBLE DIAPHRAGM PUMP

NDP-H40
NDP-H50
NDP-H500
NDP-H80

WARNING



- For your own safety, be sure to read these procedures carefully before performing maintenance on this product. After reading this document, be sure to keep it handy for future reference.

This maintenance manual covers what you should know about maintenance of the Yamada NDP-H40 series, NDP-H50 series, NDP-H500 series and NDP-H80 series Diaphragm Pumps.

This edition is based on the standards for the September 2024 production run. Remember, the specifications are always subject to change; therefore, some of the information in this edition may not apply to new specifications.

Warnings and Cautions

For safe use of this product, be sure to note the following: In this document, warnings and cautions are indicated by symbols. These symbols are for those who will operate this product and for those who will be nearby, for safe operation and for prevention of personal injury and property damage. The following warning and caution symbols have the meanings described below. Be sure to remember their meanings.



WARNING : If you ignore the warning described and operate the product in an improper manner, there is danger of serious bodily or property damage.



CAUTION : If you ignore the caution described and operate the product in an improper manner, there is danger of personal injury or property damage.

Furthermore, to indicate the type of danger and damage, the following symbols are also used along with those mentioned above:



This symbol indicates a DON'T, and will be accompanied by an explanation on something you must not do.



This symbol indicates a DO, and will be accompanied by instructions on something you must do in a certain situation.

WARNING



- Before starting maintenance work, cut off the feed air and clean the pump. If air pressure or residue remain in the pump, there is danger of explosion, or possible poisoning resulting in serious injury or death if chemicals adhere to the skin or are accidentally swallowed. (For details on cleaning the pump, refer to Chapter 6 of the operating manual.)



- When replacing parts, be sure to use the recommended genuine parts or Equivalents. Use of other parts may cause a malfunction of the product. (Refer to Parts list the separate sheets.)

CAUTION



- When it is instructed that special tools must be used, be sure to use the specified tools. Otherwise, the pump may be damaged.



- Refer to “10.1 Specifications” in the Operation Manual. Also, remember that the pump is heavy, and extreme care must be taken when lifting it.

Table of Contents

•Warnings and Cautions	
•Table of Contents	
1.Principles of operation	1
2.Maintenance and Tools	
2.1 Maintenance	1
2.2 General tools	1
2.3 Special tools	1
2.4 Misc.	1
3.Ordering Replacement parts	2
4.Balls and Valve seats	
4.1 Removal	
■ BA□, BS□, BF□ types	2
■ NDP-H40 BP□ types	3
■ NDP-H50•H80 BP□ types	4
4.2 Inspection	5
4.3 Installation	5
5.Diaphragm, Center rod and Center bushing	
5.1 Removal	
■ BA□, BS□, BF□ types	6
■ BP□ type	6
5.2 Inspection	7
5.3 Installation	
■ B□C, B□N, B□E, B□V, B□H, B□S, B□H/T types	7
■ B□T type	8
6.Throat bearing and Pilot valve assembly	
6.1 Removal	9
6.2 Inspection	9
6.3 Installation	9
7.Valve Body Assembly	
7.1 Removal	10
7.2 Inspection	11
7.3 Installation	11
8.Valve switcher	
8.1 Removal	12
8.2 Inspection	12
8.3 Installation	12
9.Retightening of Tie rods	13

1.Principles of operation

There are two diaphragms fixed to the center rod, one at each end. When compressed air is supplied to air chamber b (right side, see Fig.1.1), the center rod moves to the right, the material in material chamber B is pushed out, and at the same time material is sucked into material chamber A.

When the center rod is moved full-stroke to the right, the air switch valve is switched, compressed air is sent to air chamber a (left side, see Fig.1.2), and the center rod moves to the left. The material in material chamber A is pushed out, and at the same time material is sucked into material chamber B.

Through repetition of this operation, material is repeatedly taken in and discharged out.




Fig. 1.1





Fig. 1.2

2.Maintenance and Tools

2.1 Maintenance

It is recommended that the pump should be regularly inspected, as this kind of diaphragm pump can be used in many different circumstances such as pressures, temperatures, viscosities, or corrosiveness. It's very useful for your future reference to keep records of the pump conditions for every inspection.

The regular inspection includes the air valve, diaphragms, balls, valve seats, or O-rings.

When it comes to diaphragms, in particular, both of the diaphragms should be replaced at one time, as they tend to be worn out or have some cracks on the surfaces. Please refer to 'usage range' in each section regarding the frequency of the replacement of the other spare parts.

2.2 General tools

- Socket wrenches 13 mm, 17 mm, 19 mm (except with the NDP-H40 BP□)
24 mm (BA□, BS□, BF□)
- Hexagonal box wrenches 3 mm, 5 mm
- Small crowbars 2 (B□C, B□N, B□E, B□V)
- Open-end wrenches 17 mm (NDP-H40 BP□), 19 mm (BA□, BS□, BF□)
24 mm (BA□, BS□, BF□)
- Phillips-head screw driver

2.3 Special tools

- Outer disk wrench (sold separately)

Purpose: Removing the center disk of BP□ type




Fig.2.1

- Guide wrench adapter (sold separately)

Purpose: Removing the throat bearing




Fig.2.2

2.4 Misc.

- Assembly oil Turbine oil none addition class 1 (equivalent to ISO VG32 grade)
- Nuts M16 X 1.5
- Thread locker
- Grease Urea grease grade (NLGI) No. 2
Shell Alvania Grease S1


3.Ordering Replacement parts

For accurate and speedy shipment of parts, be sure to order the right parts for your model to distributor. Indicate the part numbers, descriptions, and quantities.


4. Balls and Valve seats

4.1 Removal


■BA□, BS□, BF□ types



- Remove the 6 (8 on the NDP-H500, NDP-H80) retainer bolts 1 from the out manifold, and remove the out manifold. [Fig.4.1]




- Remove the ball, valve seat and O ring. [Fig.4.2]




- Remove the 6 (8 on the NDP-H500, NDP-H80) retainer bolts 2 from the in manifold, and remove the in manifold. [Fig.4.1]
- Remove the ball, valve seat and O ring. [Fig.4.3]


■NDP-H40 BP□ type



- Remove the 8 retainer bolts 1 from the out manifold, and remove the out manifold. [Fig. 4.4]




- Remove the ball, valve seat and O ring. [Fig. 4.5]




- Remove the 8 retainer bolts 2 from the in manifold, and remove the in manifold. [Fig. 4.4]
- Remove the ball, valve seat and O ring. [Fig. 4.6]


■ NDP-H50·H80 BP□ types



- Remove the 6 (8 on the NDP-H80) retainer bolts 1 from the out manifold, and remove the protector and out manifold. [Fig.4.7]




- Remove the ball, valve guide (only NDP-H80), valve seat and O ring. [Fig.4.8]



- Remove the 6 (8 on the NDP-H80) retainer bolts 2 from the in manifold, and remove the protector and in manifold. [Fig.4.7]
- Remove the ball, valve guide (only NDP-H80), valve seat and O ring. [Fig.4.9]

4.2 Inspection




▪ Ball [Fig.4.10]

Measure the outside diameter, and if it is outside the usable range, replace the ball.

Usable range of ball

NDP-H40	SØ 45.0 - SØ 51.5 mm
NDP-H50 NDP-H500	SØ 56.7 - SØ 64.9 mm
NDP-H80	SØ 81.0 - SØ 92.7 mm



▪ Valve seat [Fig.4.11]

If you find a scar on the seat surface, please replace it for the new one.

Measure the dimension shown at left, and if it is outside the usable range, replace the seat.

Usable range of valve seat


	B□C, B□N, B□E B□V, B□H, B□S, B□H/T	B□T
NDP-H40	4.6 - 11.5 mm	1.7 - 4.2 mm
NDP-H50 NDP-H500 NDP-H80	5.0 - 12.5 mm	

▪ O ring (other than PTFE)

If O ring is worn out or cracked, replace it.

4.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.



Tightening torque for manifold retainer bolts

NDP-H40	BA□、BS□、BF□	25 N·m
	BP□、BV□	20 N·m
NDP-H50 NDP-H80	BA□、BS□、BF□ BP□、BV□	25 N·m
NDP-H500	BS□	20 N·m

<NOTE>

▪ Make sure there is no dust on the seal surface and the seal is not damaged.

▪ Match the convex and concave parts of the protector.

[Fig.4.12] (NDP-H50 BP□・H80 BP□)

5. Diaphragm, Center rod and Center bushing

5.1 Removal

■BA□, BS□, BF□ types




Fig.5.1




Fig.5.2-1

Fig.5.2-2




Fig.5.3

- Remove the ball and valve seat etc. (see “4.1 Removal BA □, BS□, BF□ types”)
- Remove the 16 (24 on the NDP-H80) retainer bolts from the out chamber, and remove the out chamber. [Fig.5.1]
- Remove the nut on one side of the center rod. Then, remove the coned disk spring, center disk, diaphragm and center bushing on the same side. [Fig.5.2-1]
- Pull out the other center disk, diaphragm and center bushing together with the center rod from the main body. [Fig.5.2-1]
- Remove the center disk from one side using the general tool. [Fig.5.2-2]
- Then, remove the diaphragm, center disk inside and center bushing on the same side. Pull out the other diaphragm, center disk inside and center bushing together with the center rod from the main body. [Fig.5.2-2]
- Remove the other nut using the double-nut method. Then, remove the coned disk spring, center disk, diaphragm and center bushing. (excluding H500BS□) [Fig.5.3]
- Remove the other center disk using the double-nut method. Then, remove the center disk, diaphragm and center bushing. (only H500BS□) [Fig.5.3]

<NOTE>

- Be careful not to damage the center rod and center bushing.

■BP□ type




Fig.5.4




Fig.5.5




Fig.5.6

- Remove the ball etc. (see “4.1 Removal BP□ type”)
- Remove the 8 (4 on the NDP-H40) retainer bolts from the stand body, and remove the stand body. [Fig.5.4]
- Remove the 16 (24 on the NDP-H80) retainer bolts from the out chamber, and remove the out chamber. [Fig.5.5]
- Remove the center disk from one side using the Outer disk wrench (special tool: Part No. 771868). [Fig.5.6]
- Then, remove the diaphragm, center disk inside and center bushing on the same side. Pull out the other diaphragm, center disk inside and center bushing together with the center rod from the main body.




Fig.5.7

- Remove the other center disk using the double-nut method. Then, remove the center disk, diaphragm and center bushing. [Fig.5.7]

<NOTE>

- Be careful not to damage the center rod and center bushing.

5.2 Inspection




Fig.5.8




Fig.5.9

- Diaphragm

If the diaphragm is worn out or damaged, replace it.

Never replace just one diaphragm.

Frequency of inspecting the diaphragms
(Transferring water at room temperature)

CR, NBR, EPDM	10,000,000 cycle
FKM	2,500,000 cycle
PTFE	3,000,000 cycle
TPEE, TPO	15,000,000 cycle

*The standard in our facility is 'Air supply pressure 0.5 MPa with no discharge pressure.'

*It's recommended to conduct an inspection, if 3 months have passed since you start using the pump, or if the number of cycles reaches the above.

- Center rod [Fig.5.8]

If you find a scar on the sliding parts, please replace it for the new one.

Measure the diameter, and if it is outside the usable range, replace the rod.

Usable range of center rod

Ø 17.93 - Ø 18.00 mm

- Center bushing [Fig.5.9]

If you find a scar on the sliding parts, please replace it for the new one.

Measure the diameter, and if it is outside the usable range, replace the rod.

Usable range of center bushing

Ø 24.93 - Ø 25.00 mm

5.3 Installation

■B□C, B□N, B□E, B□V, B□H, B□S, B□H/T types

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.




Fig.5.10




Fig.5.11

- Apply assembly grease(urea) to center rod, and insert it into the main body. [Fig.5.11]
- Apply assembly grease(urea) to the outer surface of the center bushing and then attach it on the center rod.
- Keep the marking "OUTSIDE" to liquid end for CR, NBR, EPDM, FKM diaphragms.
Keep the convex side to the outside for TPEE, TPO diaphragms. [Fig.5.10]
- Tighten the center disk using the Outer disk wrench (special tool: Part No.771868) for the BP□ type. Apply proper thread locker to the thread of center disk. (No coned disk springs and nuts are needed.)
- For H500 type, apply proper Thread locker to the thread of center disk and then tighten the center disk. (No coned disk springs and nuts are needed.)

Tightening torque for center rod

BA□, BS□, BF□	60 N·m
BP□	50 N·m




Fig.5.12


- Draw the center disk to one side (exclude B□H, B□S, B□H/T types cf. Fig.5.10).and install the out chamber. tighten the bolts temporarily.
- Grip the inside center disk using crowbars and draw it to the opposite side, then turn the diaphragm over. (exclude B□H, B□S, B□H/T types) [Fig.5.12, 5.13]
- And install the out chamber. Tighten the bolts temporarily.
- After installation of the out chambers on both sides, place the pump on a flat surface and stand the pump upright for further assembly.

Tightening torque for out chamber.

BA□, BS□, BF□	40 N•m
BP□	35 N•m

<NOTE>

- Make sure there is no dust on the seal surface in order to prevent seal damaged.
- Be careful not to damage the R portion of the air chamber using a crowbar, etc.
- Tighten the bolts gradually in a diagonal sequence with even torque.



■B□T type

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.




Fig.5.14

- Apply assembly grease(urea) to center rod, and insert it into the main body. [Fig.5.11].
- Apply assembly grease(urea) to the outer surface of the center bushing and then attach it to the center rod.
- Keep the convex side to the outside (cf. Fig.5.14).
- Put the O rings to both sides of the diaphragm. (cf. Fig.5.14)
- Tighten the center disk using the Outer disk wrench (special tool: Part No. 771868) for the BPT types. Apply proper thread locker to the thread of center disk. (No coned disk springs and nuts are needed.)

Tightening torque for center rod

BAT, BST, BFT	60 N•m
BPT	50 N•m


- Tighten the out chamber temporarily at first. After installation of the out chambers on both sides, place the pump on a flat surface and stand the pump upright for further assembly.

Tightening torque for out chamber

BAT, BST, BFT	40 N•m
BPT	35 N•m


<NOTE>

- Make sure there is no dust on the seal surface in order to prevent seal damaged.
- Replace the PTFE O ring by new one.
- Tighten the bolts gradually in a diagonal sequence with even torque.




6. Throat bearing and Pilot valve assembly

6.1 Removal




- Remove the diaphragm and center rod (see “5.1 Removal”).
- Unscrew the tapping screws with a Phillips-head screw driver. [Fig. 6.1]
- Remove the throat bearing using a Guide wrench adapter (804129). [Fig. 6.1]



- Remove the O rings from the throat bearing. [Fig. 6.2]

6.2 Inspection



- Throat bearing [Fig. 6.3]
Measure the inside diameter, and if it is outside the usable range, replace the throat bearing.


Usable range of throat bearing

Ø 25.04 - Ø 25.15mm

- O ring
If the O ring is worn out or cracked, replace it.

6.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.



- Screw the throat bearing all the way into the air chamber and then back it to align the bolt holes.
- Tighten the tapping screws.

<NOTE>

- Make sure there is no dust on the seal surface and the seal is not damaged.
- Inner O ring grease(urea) can be applied fully.

7. Valve Body Assembly

7.1 Removal




Fig. 7.1

- Remove the silencer.
- Remove the 2 retainer bolts from the valve body, and remove the valve body. [Fig. 7.1]
- Disconnect in the same way both up and down.




Fig. 7.2

- Remove the 4 bolts from the guide plate with a Phillips-head screw driver, and remove the guide plate and block. [Fig. 7.2]
- Remove the hexagon socket set screw from the guide plate, and remove the spring and ball. [Fig. 7.2]





Fig. 7.3

- Remove the valve seat and gasket. [Fig. 7.3]

7.2 Inspection




- Block [Fig.7.4]

Measure the thickness and if it is not within the permissible range, replace with a new one. Also, replace the block if its sliding surface is worn out.

Usable range of Block

11.4 mm - 11.55 mm



- Valve seat [Fig.7.5]

Measure the thickness and if it is not within the permissible range, replace with a new one. Also, replace the block if its sliding surface is worn out.

Usable range of Valve seat

8.75 mm - 9.00 mm

- Gasket, Ball

If the Gasket and Ball are worn out or cracked, replace them.

<NOTE>

- Apply enough grease(urea) to the spring and ball.

7.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.

<NOTE>

Apply proper Thread locker to the guide plate retainer bolts.

Tightening torque 3N·m

8. Valve switcher

8.1 Removal




Fig.8.1




Fig.8.2

- Remove the diaphragm and center rod. (see “5.1 Removal”)
- Remove the 12 retainer bolts from the air chamber, and remove the air chamber.
- Remove the valve body assembly. (see “7.1 Removal”)
- Unscrew the two bolts on each retainer and then remove both retainers.

<NOTE>

- Be very careful when removing the retainers. the spring may pop out.
- Remove the spring retainers, bushings, springs, trip arms and O rings from each side.

<NOTE>

- Be careful not to drop the trip arms when removing them.
- Pull out the pins in the direction of the arrow.
- Remove the valve switcher in the direction of the arrow.

8.2 Inspection




Fig.8.3




Fig.8.4

- Bushing [Fig.8.3]

Measure the inside diameter Outside diameter, and if it is outside the usable range, replace the throat bearing.

Usable range of Bushing

Inside diameter	7.5 mm - 8.1 mm
Outside diameter	11.5 mm - 12 mm

- Valve switcher [Fig.8.4]

Measure the inside diameter, and if it is outside the usable range, replace the throat bearing.

Usable range of Valve switcher

17.80 mm - 18.15 mm

8.3 Installation

For installation, see [Exploded View] on the separate sheet and install in the reverse order of disassembly.




Fig.8.5

Tightening torque for air chamber retainer bolts

20 N·m


- Attach the trip arm in a way that the valve switcher and pin fit in each groove on the trip arm. [Fig.8.5]

<NOTE>

- Use grease (alvania) to set the pins.

9. Retightening of Tie rods

■ Metal type




- All bolts should be retorqued:
 - (1) Right before start up.
 - (2) There are any leaks of material on daily inspecting a pump.


		Retain bolts for the out chamber.	Retain bolts for the manifold.
NDP-H40	BA□	40 N·m	25 N·m
NDP-H50	BS□		
NDP-H80	BF□		
NDP-H500	BS□	40 N·m	20 N·m

<NOTE>

- Retighten the Out chamber and then the manifold in this order. [Fig.9.1]
- Tighten the bolts in the order shown.



■ Plastic type




- All bolts should be retorqued:
 - (1) Right before start up.
 - (2) There are any leaks of material on daily inspecting a pump.

		Retain bolts for the out chamber.	Retain bolts for the manifold.
NDP-H40	BP□	35 N·m	20 N·m
NDP-H50			
NDP-H80			

<NOTE>

- Retighten the Out chamber and then the manifold in this order. [Fig.9.2]
- Tighten the bolts in the order shown.



YAMADA CORPORATION

INTERNATIONAL DEPARTMENT

1-1-3, Minami-Magome, Ota ku, Tokyo, 143-8504, Japan

PHONE : +81-(0)3-3777-0241

FAX : +81-(0)3-3777-0584

E-mail : intl@yamadacorp.co.jp

Web : www.yamadacorp.co.jp

YAMADA (THAILAND) CO., LTD

41/79 Moo 6, Bangcha-long, Bangplee, Sumutprakarn 10540, Thailand

PHONE : +66-(0)2-130-0990

FAX : +66-(0)2-130-0993

E-mail : sales@yamada-th.com